




# LOWER OVEN PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
(Black) (Designer White) (Biscuit) (S.Steel)

27" BUILT-IN ELECTRIC  
DOUBLE OVEN  
STD-CLEAN LOWER  
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER OVEN PARTS


For Models:RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12

(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			4	4448520	Bumper, Door	37	4451354	Fuse-Thermal
			6	4450935	Plug, Door		4449809	Screw
			7	4455285	Top, Chassis	43	4455529	Base, Chassis
			9	4452159	Tube, Vent		4449154	Screw
				3196176	Screw	49	4448933	Retainer, Gasket
			10	4451664	Fan & Bracket Assy.		4449154	Screw
				4449809	Screw	50	4451747	Cover, Back
			11	4452368	Oven Light Assy		4449809	Screw
			12	4452166	Bulb, Light	51		Trim, Bottom
			13	4452165	Lens, Light		4448475	Black Model
	4449809	Screw		4448476	White Model			
14	4455611	Frame, Front		4452414	Biscuit Model			
	4449040	Screw		3400832	Screw			
	4450118	Nut	53	4449845	Support, Bracket			
15	4450492	Gasket, Door		4449809	Screw			
19	4451477	Support, Insulation	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>					
25	4455641	Side, Chassis (R.H. & L.H.)	<b>INSULATION</b>					
	4449809	Screw		4449315	Insulation, Wrap			
26	4452233	Back, Chassis		4450364	Insulation, Back			
	4449809	Screw						
27		Liner, Oven (Not serviceable)						
29	4455636	Sensor						
	4449154	Screw						

# UPPER OVEN PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
(Black) (Designer White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN PARTS

For Models:RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12

(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	4455605	Reciever, Hinge Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	4452312	Switch, Micro
6	4452224	Solenoid
7	4451426	Switch, Micro
8	4451537	Spring, Latch
9	4452158	Tube, Vent
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
14	4455611	Frame, Front
	4449040	Screw

Illus. No.	Part No.	DESCRIPTION
15	4455381	Gasket, Door
19	4451477	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450581	Right Side
	4450582	Left Side
	4448444	Grommet
	4449154	Screw
24	4451896	Latch Assy
	4449809	Screw
25	4455641	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
	4449154	Screw
34	4452266	Vent, Center

Illus. No.	Part No.	DESCRIPTION
37	4451442	Thermostat (TOD) (Temp.) SPST
	4449809	Screw
43	4455529	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw


## FOLLOWING PARTS NOT ILLUSTRATED

### INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back

# LOWER OVEN DOOR PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
 (Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4455617	Door Liner
3	4449253	Glass, Inner
5	8300777	Retainer, Glass
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

6		Hinge, Door
	8300565	R.Side (L.Brown)
	8300566	L.Side (L.Brown)
	8300780	R.Side (Grey)
	8300781	L.Side (Grey)
	4449743	Screw
12		Door Glass, Assy
	4452062	Black Model
	4452063	White Model
	8300257	Biscuit Model
	8300994	S.Steel Model


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

13		Door Handle
	4448405	Black Model
	4448406	White Model
	8300255	Biscuit Model
14		Bracket, Handle
	4451040	Screw
21		Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4452119	Biscuit Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER OVEN DOOR PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
 (Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	4455617	Door Liner
2	8300569	Hinge, Door
	8300570	R.Side (Green)
	8300571	L.Side (Green)
	8300572	R.Side (White)
	8300572	L.Side (White)
	4449743	Screw
3	4449253	Glass, Inner
4	4451721	Insulation, Door


Illus. No.	Part No.	DESCRIPTION
5	8300777	Retainer, Glass
	4449809	Screw
7	4449257	Glass, Inner
12	4452062	Door Glass, Assy
	4452063	Black Model
	4452063	White Model
	8300257	Biscuit Model
	8300905	S.Steel Model
13	4448405	Door Handle
	4448405	Black Model
	4448406	White Model
	8300255	Biscuit Model

Illus. No.	Part No.	DESCRIPTION
14	4450813	Bracket, Handle
	4451040	Screw
19	4450361	Shield, Heat
	4449809	Screw
20	4451668	Retainer, Glass
	4449809	Screw
21	8300819	Seal, Door Top
23	4450863	Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4452119	Biscuit Model
24	4455256	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
 (Black) (Designer White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448715	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
 (Black) (Designer White) (Biscuit) (S.Steel)



**Illus. Part**  
**No. No. DESCRIPTION**

NOTE: The screws and nuts required to attach a part are listed immediately following that part.


1	Control Panel Assy. W/Membrane Switch
	8300429 Black Model
	8300430 White Model
	8300531 Biscuit Model
	8281179 Screw
2	4451033 Gasket, Control Panel
3	4452890 Microcomputer
	4449745 Screw
	3400832 Screw
4	3192690 Insulator, Membrane Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# TOP VENTING PARTS

For Models: RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	4455334	Blower, 60MM
	4455352	Bracket, Blower
3	4451758	Foam, Block
4	4455178	Elbow, Vent-Top

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

5	4455177	Elbow, Vent-Bottom
6	4451789	Plate, Mounting
7	8300642	Transformer, Control
11	4449868	Block, Terminal
	3400080	Screw
13	4448548	Vent, (Control Panel)
	4450038	Screw
14	4451597	Right Side, Control Top
	4451598	Left
	4449809	Screw
	4449154	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
	112432	Nut
18	4452366	Cover, Top Front
	4449809	Screw
19	4454943	Plate, Mounting Fan
20	4451985	Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models:RBD275PDB12, RBD275PDQ12, RBD275PDT12, RBD275PDS12  
(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**PAINT, TOUCH-UP (1/2oz.)**

72017 White  
261869 Cord Brown  
72032 Black

**PAINT, SPRAY**

350930 White  
261900 Citrine White  
830864 Black

**ADHESIVE**

591014 Adhesive  
Loctite (1/3 oz.)  
482338 Sealer, Silastic  
(3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**SPLICING WIRES--25FT.**

**LENGTH**

242828 Wire (12 Ga.  
150 c Black)  
242820 Wire (14 Ga.  
150 c Black)  
242821 Wire (14 Ga.  
150 c Blue)  
242822 Wire (14 Ga.  
150 c Brown)  
242830 Wire (14 Ga.  
200 c Brown)  
242823 Wire (14 Ga.  
150 c Green)  
242824 Wire (14 Ga.  
150 c Orange)  
242829 Wire (12 Ga.  
150 c Red)  
242825 Wire (14 Ga.  
150 c Red)  
242831 Wire (14 Ga.  
200 c Red)  
242826 Wire (14 Ga.  
150 c White)  
242827 Wire (14 Ga.  
150 c Yellow)  
242832 Wire (14 Ga.  
200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**WIRING HARNESS PARTS**

4455739 Harness, Wire  
(Main)  
4450953 Conduit, Double  
4448664 Clamp  
4449809 Screw  
112432 Nut  
4450800 Screw, Ground  
4452222 Spacer, Harness  
4454835 Tie, Cable  
4451761 Support, Wiring

**Miscellaneous**

814381 Hinge Pin Kit  
4448950 Screw, Install (4)