



## **PROGRAM RE2000 Alpha**

1. Turn on scanner.
2. Press MANUAL.
3. To program frequencies:
  - a. Press Frequency number, ENTER;
  - b. Press Channel/Car #, ENTER.
4. To program RE Code:
  - a. Press ENTER;
  - b. Press RE Code#, ENTER.
5. To program Alpha:
  - a. Press & hold MANUAL for 3 beeps;
  - b. Turn Channel knob to desired letter;
  - c. Press MANUAL to move to next letter (up to 7 letters).
  - d. ENTER.
6. To program next Frequency / RE Code / Alpha, Repeat Steps 3 thru 5.